


MPCBs MPX³

accessories



Pack	Cat. Nos	Auxiliary contacts	Pack	Cat. Nos	Direct adaptator and mounting unit
		2-pole			For mounting CTX ³ contactors under MPX ³ MPCBs
		Side mounting			Direct adaptators
		Mounting on the left side of MPCBs			Used to connect MPX ³ directly with the contactor
		One module per MPCB	2	4 174 48	For MPX ³ 32S with CTX ³ 22 AC (p. 176)
2	4 174 00	1 NO + 1 NC	2	4 174 49	For MPX ³ 32S with CTX ³ 22 DC (p. 176)
2	4 174 01	2 NO	2	4 174 50	For MPX ³ 32H/32MA with CTX ³ 22 AC (p. 176)
2	4 174 02	2 NC	2	4 174 51	For MPX ³ 32H/32MA with CTX ³ 22 DC (p. 176)
		Front mounting	2	4 174 52	For MPX ³ 32S with CTX ³ 40 AC (p. 176)
		One module per MPCB	2	4 174 53	For MPX ³ 32S with CTX ³ 40 DC (p. 176)
10	4 174 03	1 NO + 1 NC	2	4 174 54	For MPX ³ 32H/32MA with CTX ³ 40 AC (p. 176)
10	4 174 04	2 NO	2	4 174 55	For MPX ³ 32H/32MA with CTX ³ 40 DC (p. 176)
10	4 174 05	2 NC	2	4 174 56	For MPX ³ 63H with CTX ³ 65 AC with lug type terminals (p. 176)
		Alarm contacts	2	4 174 57	For MPX ³ 63H with CTX ³ 65 DC with cage type terminals (p. 176)
		1 NO + 1 NC	1	4 174 58	For MPX ³ 100H with CTX ³ 100 AC with cage type terminals (p. 176)
		Any trip alarm contact	1	4 174 59	For MPX ³ 100H with CTX ³ 100 DC with cage type terminals (p. 176)
		Operate in case of trip			Mounting unit
		Mounting on the left side of MPCBs			This device is used for joining together MPX ³ MPCBs and CTX ³ contactors
		Set alarm contact first in case of using auxiliary contact together (MPX ³ 63H can not accept auxiliary contact and alarm contact together)			Screws not supplied
1	4 174 06	For MPX ³ 32	1	4 174 60	For MPX ³ 32S/32H/32MA
1	4 174 08	For MPX ³ 63 and 100	1	4 174 61	For MPX ³ 63H
		Magnetic trip alarm contact	1	4 174 62	For MPX ³ 100H
		Operate in case of instantaneous trip			Rotary handle
		Mounting on the left side of MPCBs			Mounting on panel's door to control the MPX ³
		Set alarm contact first in case of using auxiliary contact together	1	4 174 63	For MPX ³ 32H and 32 MA
2	4 174 07	1 NO + 1 NC	1	4 174 64	For MPX ³ 63H
		Shunt release	1	4 174 65	For MPX ³ 100H
		Mounting on the right side of MPCBs			Phase busbar
		One release per MPCB			For parallel connection of MPX ³
1	4 174 10	24 V - 50 Hz / 28 V - 60 Hz			For MPX³ 32S, 32H and 32MA
1	4 174 11	110 V - 50 Hz / 120 V - 60 Hz	10	4 174 71	2 devices - rated current 63 A
1	4 174 12	220-230 V - 50 Hz / 240-260 V - 60 Hz	10	4 174 73	3 devices - rated current 63 A
1	4 174 13	380-400 V - 50 Hz / 440-460 V - 60 Hz	10	4 174 75	4 devices - rated current 63 A
		Undervoltage release	10	4 174 76	5 devices - rated current 63 A
		Mounting on the right side of MPCBs	4	4 174 77	Feeder for phase busbar - rated current 32 A
		One release per MPCB			For MPX³ 63H
		Without auxiliary contact			Rated current 108 A
1	4 174 20	24 V - 50 Hz / 28 V - 60 Hz	4	4 174 72	2 devices
1	4 174 21	110 V - 50 Hz / 120 V - 60 Hz	4	4 174 74	3 devices
1	4 174 22	220-230 V - 50 Hz / 240-260 V - 60 Hz			Enclosures for MPX³ 32H and 32MA
1	4 174 23	380-400 V - 50 Hz / 440-460 V - 60 Hz			IP 65 enclosure to use in dusty areas as well as in presence of corrosive gas or liquid
		With 2 NO auxiliary contacts			Yellow/red rotary handle
		Can not attach to MPX ³ 32S	1	4 174 80	With black rotary handle
1	4 174 30	24 V - 50 Hz / 28 V - 60 Hz	1	4 174 81	
1	4 174 31	110 V - 50 Hz / 120 V - 60 Hz			
1	4 174 32	220-230 V - 50 Hz / 240-260 V - 60 Hz			
1	4 174 33	380-400 V - 50 Hz / 440-460 V - 60 Hz			
		Dial Cover			
		Sealable cover to protect the set value from the operation that is not intended			
400	4 174 79	For all types of MPX ³			