



# Supply busbars, entry terminals


"standard" distribution




4 049 26



4 049 44




4 049 17




4 049 89


4 049 90




4 049 38



4 049 11




4 049 87




4 049 91


4 049 93



4 049 40




4 049 13



4 049 19



4 049 42



4 049 15



4 049 05

4 049 04







4 049 94


4 049 95

Selection of protections for supply busbars p. 298




Pack	Cat.Nos	Prong-type supply busbars	
		<b>Universal single pole + neutral</b>	
		Reversible: blue for neutral, black for live	
		Length	Max. number of devices connected
20	4 049 26	1 row	13
20	4 049 28	1 row	18
10	4 049 37	Meter	57
10	4 049 33	Meter	37
		<b>Single pole for auxiliary</b>	
10	4 049 38 <sup>1</sup>	1 row	6
10	4 049 39	Meter	28
		<b>Double pole</b>	
10	4 049 40 <sup>1</sup>	1 row	6
10	4 049 66 <sup>1</sup>	1 row	9
10	4 049 41	Meter	28
		<b>Double pole balanced on 3 phases</b>	
10	4 049 42 <sup>1</sup>	1 row	4
10	4 049 43	Meter	19
		<b>Three pole</b>	
10	4 049 34	Meter	16
		<b>Three pole for auxiliary</b>	
10	4 049 44 <sup>1</sup>	1 row	3
10	4 049 45	Meter	14




Pack	Cat.Nos	Fork-type supply busbars	
		<b>Single pole</b>	
		Length	Max. number of devices connected
10	4 049 11 <sup>1</sup>	1 row	12
10	4 049 12	Meter	57
		<b>Double pole</b>	
10	4 049 13 <sup>1</sup>	1 row	6
10	4 049 14	Meter	28
		<b>Double pole balanced on 3 phases</b>	
10	4 049 15 <sup>1</sup>	1 row	6
10	4 049 67 <sup>1</sup>	1 row	9
10	4 049 16	Meter	28



Pack	Cat.Nos	Fork-type supply busbars (continued)	
		<b>Three pole</b>	
10	4 049 17 <sup>1</sup>	1 row	4
10	4 049 18	Meter	19
		<b>Three pole for 1.5 module/pole MCBs</b>	
10	4 049 87 <sup>1</sup>	1 row	12
		<b>Three pole for auxiliary</b>	
10	4 049 10	Meter	16
		<b>Four pole</b>	
10	4 049 19 <sup>1</sup>	1 row	3
10	4 049 20	Meter	14
		<b>Protection</b>	
20	4 049 88	<b>Protection of prongs</b> 12 modules Can be cut to length	
40	4 049 89	<b>Protection of prong-type and fork-type supply busbar ends</b> For single pole/single pole + neutral supply busbars Cat.Nos 4 049 26/28/33/37	
20	4 049 90	For three pole supply busbars Cat.Nos 4 049 34/42/43	
20	4 049 91	For four-pole supply busbars Cat.Nos 4 049 40/41/44/45/66/67	
20	4 049 94	For double pole supply busbars Cat.Nos 4 049 14/38/39	
20	4 049 95	For three-pole supply busbars Cat.Nos 4 049 17/18/87	



Pack	Cat.Nos	Entry terminals	
20	4 049 05	For universal single pole + neutral or single pole supply busbars Cross section: 4 to 25 mm <sup>2</sup> - IP 2X	
10	4 049 04	For fork-type supply busbars Cross section: 4 to 25 mm <sup>2</sup> - IP 2X	
20	4 049 06	For all supply busbars Cross section: 6 to 35 mm <sup>2</sup>	



1: Filled with end protection